# AUTOLINK Telematics Supported Features

**√ Supported**
**X Not tested yet**
**! Caution, see Notes**

**NOTES:** (1) Connect the AUTOLINK device using the HRN-MCAR-01 directly into the Black RS-232 port.
(2) Blade-AL (64) MUST be used for full connectivity with remote starter functions.
(3) Engine WILL Start
(4) Must enable in the remote start options, Smart Phone Baud Rate to Option #1 (9600)
(5) Connect the AUTOLINK device using the HRN-MCAR-01 and HRN-LLRS-01 with White 4-pin connector. Connect to White data port on the side of the remote start unit.
(6) **NOT RECOMMENDED ON MANUAL TRANSMISSION VEHICLES**
(7) Does not report back run time

| Remote Starter Brands | ADS | ADS | ADS | CrimeStopper | CrimeStopper | Compustar | DEI | Fortin |
|---|---|---|---|---|---|---|---|---|
| Remote Starter Models | HC3 | ADS-CH4<br>ADS-CH5<br>ADS-CH7<br>ADS-F01<br>ADS-GM10<br>ADS-GM2<br>ADS-GM7<br>ADS-HA6<br>ADS-HA7<br>ADS-NI5 | ADS-BM1<br>ADS-BZ1<br>ADS-BZ2<br>ADS-BZ3<br>ADS-BZ4 | RS00-G5<br>RS1-G5<br>RS3-G5<br>RS4-G5<br>RS7-G5 | SP-402<br>SP-502 | CM-6200<br>CM-7200 | DBALL2<br>4X10<br>5X10 | EVO-ALL<br>EVO-ONE |
| Notes | (1) | (1) | (1,3) | (4,5) | (4,5) | (1,2,3) | (7) | (7) |
| Basic Functions | | | | | | | | |
| Lock | √ | √ | √ | √ | √ | √ | √ | √ |
| Unlock | √ | √ | √ | √ | √ | √ | √ | √ |
| Remote Start | √ | √ | √ | √ | √ !(6) | √ | √ !(6) | √ !(6) |
| Runtime Extend | √ | | | | | | | |
| Start Confirmation W/ Phone Unlocked | √ | √ | √ | √ | √ | √ | √ | √ |
| Start Confirmation W/ Phone Locked | √ | √ | √ | √ | √ | √ | √ | √ |
| Runtime Displayed After Remote Start | √ | √ | √ | √ | √ | √ | X | X |
| Runtime Displayed After App Refresh | √ | √ | √ | √ | √ | √ | X | X |
| Runtime Display OFF After Stop Command | √ | √ | √ | √ | √ | √ | √ | √ |
| Press Stop Button W/ Engine ON | √ | √ | √ | √ | √ | √ | √ | √ |
| Press Stop Button W/ Engine OFF | √ | √ | 3 ! | √ | √ | 3 ! | √ | √ |
| Stop Confrimation W/ Phone Unlocked | √ | √ | √ | √ | √ | √ | √ | √ |
| Stop Confirmation W/ Phone Locked | √ | √ | √ | √ | √ | √ | √ | √ |
| Trunk Release/ Motorized Gate Open | √ | √ | √ | √ | √ | √ | √ | √ |
| AUX1 | √ | √ | √ | √ | √ | √ | √ | √ |
| AUX2 | √ | √ | √ | √ | √ | √ | √ | √ |
| AUX3 | √ | | | | | | | |
| AUX4 | √ | | | | | | | |
| STATUS | | | | | | | | |
| Battery Level | √ | √ | √ | √ | √ | √ | √ | √ |
| Generic Alarm Notification (W/ Yellow Wire Connected) | √ | √ | √ | √ | √ | √ | √ | √ |
| GPS Position | √ | √ | √ | √ | √ | √ | √ | √ |