

# 2014 or NEWER Harley-Davidson<sup>®</sup> TM400X4ad Amplifier Tuning



MOTORCYCLE AUDIO

#ROCKFORDFOSGATE



Boom!™Box  
Standard 4.3



Boom!™Box  
Premium 6.5GT



Boom!™Box  
Premium GTS



**RADIO FLASH REQUIRED**

"Rockford Fosgate Tune 2014+ All Models"

**REMOTE TURN-ON REQUIRED**

use turn-on from brake side

**REAR INPUT LEVEL: 12:00 (1/2)**

Matches the amp to the radio.  
Tells the amp where to "clip."

**FRONT INPUT LEVEL: 11:00-12:00**

When using baglids or TourPak,  
reduce fairing speaker output  
by trimming level until front &  
rear are equally balanced.

**FRONT & REAR EQUALIZER: MIN**

Adds bass & treble to  
enclosed vehicles.  
Not used on motorcycles.

**INPUT SWITCH: 2CH**

Number of inputs to feed amp.  
Flashing radio only allows  
2-ch output from radio.

**CROSSOVER FREQUENCY: 80Hz**

Tells amp what frequencies to pass.  
Motorcycles use this as a "bass blocker"  
to prevent subwoofer frequencies from  
damaging fairing and baglid speakers.  
(works with HP/AP/LP switch)

**CROSSOVER SWITCH: HP (High-Pass)**

Type of crossover needed.  
(works with crossover frequency dial)

[HP (High-Pass) allows frequencies above to pass]  
[AP (All-Pass) allows all frequencies to pass]  
[LP (Low-Pass) allows frequencies below to pass]

